

## **ANSWERING CALLS**

### **RINGING CALLS**

Lift Handset

Converse

**NOTE:** *If additional incoming CO calls are received, the **ANSWER** key **LED** will flash. Pressing the **ANSWER** key places the current call on non-exclusive hold and connects you to the next call. Press the flashing **LINE KEY** to return to the original call.*

### **VOICE ANNOUNCE CALLS**

Ensure MIC is lit

Adjust Speaker volume (up or down) as needed

Respond handsfree

**NOTE:** *The handset may be used at any time during the conversation.*

### **CAMP ON (CALL WAITING)**

Receive camp-on tone while on another call:

Replace handset to disconnect current call **OR**

Press **HOLD** and hookswitch to converse with the second party

## **PLACING CALLS**

### **INTERNAL CALLS**

Lift handset

Dial station number or "0" for the attendant **OR**

Press Feature access key or One Touch key programmed for Direct Station Selection

Voice announce after tone burst or wait for ringing call to be answered

**NOTE:** *When calling a multiline telephone, dialing "1" after the station number will change ringing to voice or voice to ringing.*

### **OUTSIDE CALLS**

Lift handset

Press idle Outside Line key **OR** Dial 9

Dial telephone number

Converse

### **LAST CO/PBX NUMBER REDIAL**

Lift Handset

Press **REDIAL (LNR/SPD)**

Dial last number Redial code - \*

Converse

### **STATION/SYSTEM SPEED DIAL**

Lift Handset

Press **REDIAL (LNR/SPD)** and dial Speed Dial Memory Location:

Station 00-19

System 20-99

**OR** Press Feature Access key or One Touch Key programmed for Station Speed Dial

Converse

### **TRUNK QUEUING**

After dialing 9 or Pressing a busy Line key and receiving a fast busy signal:

Dial Trunk Queue set code **64**

Replace Handset

**NOTE:** *When line is available, your telephone will ring; lift handset and place call.*

## **MICROPHONE CONTROL**

### **USING ACCESS CODE**

Press **FEATURE (FNC)**

Dial MIC on/off code **1**

### **USING SOFT KEY**

Press **MIC** soft key to turn MIC on/off

**NOTE:** *Lit MIC LED indicates MIC on*

## **HANDSET TRANSMIT CONTROL**

### **USING ACCESS CODE**

With outside call in progress:

Press **FEATURE (FNC)** key

Dial handset transmit on/off code **2**

### **USING SOFT KEY**

With outside call in progress:

Press **MUTE** soft key to turn handset transmit on/off.

## **SPEAKERPHONE CALLS**

Press **SPEAKER (SPKR)**; LED lights

Ensure **MIC** LED is lit

Place internal or outside call

Converse

Press **SPEAKER (SPKR)** to disconnect call.

**NOTE:** *The handset may be used at any time during the conversation. To resume handsfree operation or to monitor a call, press **SPEAKER** (LED lights) and replace handset.*

## **HOLDING CALLS**

### **NON-EXCLUSIVE HOLD**

With a call in progress:

Press **HOLD**

### **EXCLUSIVE HOLD**

With a call in progress:

Press **FEATURE (FNC)**

Press **HOLD**

**NOTE:** *To retrieve a held call, press the flashing line key or CONF key (internal calls).*

## **TRANSFERRING CALLS**

### **USING MANUAL DIAL**

With an outside call in progress:  
Press TRANSFER (TRF)  
Dial station number  
Wait for answer  
Press TRANSFER (TRF)  
Replace handset

### **USING DIRECT STATION SELECTION (DSS)**

With an outside call in progress:  
Press preprogrammed DSS key  
Wait for answer  
Press **TRANSFER (TRF)**  
Replace handset

### **USING INTERNAL LINE**

With an outside call in progress:  
Press **HOLD**  
Dial station number  
**OR Press** programmed DSS key  
Announce call indicating which Line key is being transferred  
Replace handset

**NOTE 1:** *Multiline telephone users can pickup a held line key at their convenience.*

**NOTE 2:** *This operation is not applicable when transferring to a single line telephone.*

## **CALL PICKUP**

Lift handset  
Dial Call pickup code **6#**  
Converse

## **STATION BUSY/NO ANSWER OPTIONS**

### **AUTOMATIC CALLBACK**

TO SET:  
When calling a busy multiline telephone:  
Dial automatic callback code **0**  
Replace handset

TO ANSWER:  
When both telephones are idle originating telephone rings:  
Lift handset  
Call is place automatically

### **CALLBACK REQUEST**

TO SET:  
When calling a busy or unanswered multiline telephone:

Dial callback request code #  
Replace handset

TO ANSWER:

Receive display and/or **Feature(FNC)** LED indication:

Lift handset

Dial #; request originator is automatically called

Repeat above procedure to respond to additional messages

### TO NE OVERRIDE

TO SET:

When calling a busy multiline telephone:

Dial Tone override code \* to send tone

Wait for signalled party to answer

TO ANSWER:

With call in progress:

Receive tone override signal

Press **HOLD**

Converse with second party

### VOICE OVER

ORIGINATOR:

When calling a busy multiline telephone:

Press **FEATURE (FNC)**

Dial \*

Voice Announce

ANSWER:

Receive voice over signal

Press **HOLD**

Converse with second party

Press **ANSWER** to switch between parties.

## CO/PBX DIALING OPTIONS

### SAVE AND REPEAT

SAVE:

With an originating outside call in progress:

Press **FEATURE (FNC)**

Dial #; called number is stored

Replace handset

REPEAT:

Lift handset

Press **REDIAL (LNR/SPD)**

Dial #; call is placed.

### AUTOMATIC REDIAL

After originating a busy or unanswered outside call on the handset:

Press **SPEAKER**

Replace handset

Press **FEATURE (FNC)**

Press **REDIAL (LNR/SPD)**

Call is repeatedly dialed until answered, canceled or the maximum number of redial attempts is reached.

Lift handset when the called party answers

NOTE: Press **SPEAKER** to cancel

## **CONFERENCE**

With a call in progress:

Press **CONF**

Place second call (internal or external)

Announce conference

Press **CONF** to establish conference

### **PRIVACY RELEASE**

With outside call in progress:

Press **FEATURE (FNC)**

Dial Privacy Release code **7**

NOTE: Once privacy is released, another multiline telephone with the same outside line appearance can enter the conversation by pressing the appropriate line key.

## **PAGING**

### **USING ACCESS CODE**

Lift handset

Dial paging code:

Internal – **77**

External – **75**

Page

Wait for Meet-Me answer or replace handset

### **USING SOFT KEY**

Lift handset

Press **PAGE** soft key

Page

Wait for Meet-Me answer or replace handset

### **MEET ME ANSWER**

Lift handset

Dial Meet-Me answer code:

Internal – **7\***

External – **7#**

Converse

## **CALL FORWARD ALL CALLS (CF/A)**

TO SET:

Press **FEATURE (FNC)**  
Dial Call Forward All call code **61**  
Dial destination station number  
Press **FEATURE (FNC)**

TO CANCEL:

Press **FEATURE (FNC)**  
Dial Call Forward All code **61**  
Press **FEATURE (FNC)**

### **CALL FORWARD BUSY/NO ANSWER (CFB/NA)**

TO SET:

Press **FEATURE (FNC)**  
Dial CFBNA code **62**  
Dial destination station number  
Press **FEATURE (FNC)**

TO CANCEL:

Press **FEATURE (FNC)**  
Dial CFBNA code **62**  
Press **FEATURE (FNC)**

### **DO NOT DISTURB**

#### **USING ACCESS CODE**

Press **FEATURE (FNC)**  
Dial DND on/off code **60**  
Press **FEATURE (FNC)**

#### **USING SOFT KEY**

Press **DND** soft key to turn DND on/off.

### **VOLUME CONTROL**

#### **OFF HOOK RINGING VOLUME**

Lift handset  
Dial **60**  
Dial off-hook ringing volume code **1**  
Press up or down arrow to set level  
Replace handset

#### **RINGING VOLUME**

Press **SPEAKER**  
Dial **60**

Dial ringing volume code **1**  
Press up or down arrow to set level  
Press **SPEAKER**

## **BACKGROUND MUSIC CONTROL**

Press **FEATURE (FNC)**  
Dial BGM on/off code **93**  
Press **FEATURE (FNC)**

## **PROGRAMMING**

### **RESETTING FEATURE (FNC) LED**

Press **FEATURE (FNC)**  
Dial reset code **99**  
Press **FEATURE (FNC)**

**NOTE:** *Resetting the FEATURE (FNC) LED will cancel Call Forward, Do Not Disturb and Callback Request settings.*

### **STATION SPEED DIAL – DIAL ACCESS**

Press **FEATURE (FNC)**  
Press **REDIAL (LNR/SPD)**  
Dial speed dial memory location **00-19**  
Dial trunk access code **9**  
Dial telephone number to be stored  
Press **FEATURE (FNC)**

### **FEATURE ACCESS KEYS/ONE TOUCH KEYS**

#### **SPEED DIAL – OUTSIDE NUMBERS**

Press **FEATURE (FNC)**  
Press **REDIAL (LNR/SPD)**  
Press button to be programmed  
Dial **0**  
Dial speed dial memory location number **00-99**  
Press **FEATURE (FNC)**

#### **SPEED DIAL – INTERNAL NUMBERS AND CODES**

Press **FEATURE (FNC)**  
Press **REDIAL (LNR/SPD)**  
Press button to be programmed  
Dial **1**  
Dial extension number to be stored **or** feature access code to be stored  
Press **FEATURE (FNC)**